




KEYPAD
CODE: 3350




REMOTE CONTROL UNITS
CODE: 3351 (one channel)
3352 (two channels)
3353 (four channels)




MAGNETIC CARD SWITCH
CODE: 3354



ELECTRONIC KEY LOCK
CODE: 3355



CONVERTER
CODE: 3356 (new edition: one cable per floor-abcd-serial)
3357 (old edition: one cable per floor-serial)



CONVERTER
CODE: 3358 (from common "+" to common "-")